

- User Tips -

- 1.** Reach Tape Dispenser over Box and cock wrist & Dispenser for initial tape tack.



Note-Tape Position while exiting Tape Retainer tabs.

- 2.** After initial tack tack, pull Dispenser back while rotating handle down.



Note-Tape Position

- 3.** Complete Dispenser rotation and pull towards other end of box.



Note-Tape Position

- 4.** Follow through with Taping stroke.



- 5.** Complete Taping stroke.



- 6.** Job well done!

